



- Check that the engine flange has SAE 2 dimensions and that the flywheel size is included in the table below.
- Also check the exact position of the flywheel in relation to the flange ("G" measurement).
- When ordering a pump always specify the flywheel size.
- Use the diagram above to choose and check these coupling dimensions.

Flange Size	Flywheel Size	Flywheel Dimensions		
		A	B	G
SAE 2	8"	263.525 10-3/8"	244.475 9-5/8"	61.912 2-7/16"
	10"	314.325 12-3/8"	295.275 11-5/8"	53.975 2-1/8"
	11-1/2"	352.425 13-7/8"	333.375 13-1/8"	39.687 1-9/16"

1-800-Team ABI



Email abigausa@att.net

www.abi-irrigation.com



AgriBusiness International, Inc
P.O. Box 909
Villa Rica, Georgia 30180 USA
Ph. 770-459-4401 Fx. 770-459-6877